

0 1	2	3 4	5 6	7 8 9 10 11	12	13	14 15 16	17	18						
DRAWING NUMBER	SF	HEET NUMBER		DESIGNATION											
A									A						
	SHEET	REFERENCE	≣			REVISION	SHEET	DATE	NAME						
010798	1 to 7		GENERAL I	INFORMATION											
В									В						
С									С						
D									D						
4EL703483			USER MANU	JEL											
ABBREVIATIONS LIS	 ?T		1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2												
E ADDREVIATIONS LIS	) i 								E						
NAME TYPE	Х	FONCTION		DESIGNATION											
W WATER UNIT		WATER CONTROL UNIT													
REC   RECTIFIER UNIT		OC RECTIFIER UNIT				P	1,2 Auxiliary power 6kVA->7.5kV	A 03/03/2010	DHB						
<u>INV HF-CUBICLE</u>		NVERTER UNIT TRANSFORMER				0	1,2,5,6 ADD W49, W25, W52.3	03/12/09	DMX						
CP UN CLAMP UNIT		NDUCTOR CLAMP UNIT N	MASTER COIL			N	1-2 ADD W89	10/11/09	ARF						
G						М	1, 2, 6 CABLE MODIFICATIONS	08/10/09	DNN G						
							AND SINGLE LINE UPDATE								
H						L	1-6 CABLE MODIFICATIONS AND SINGLE LINE UPDATE	24/09/09	DNN						
l., <del> </del>								00/00/00	100						
H						H G	1-7	29/06/09 10/03/09	JCS H						
						F	1,2,6	02/02/09	DMX						
						E	1-7	22/10/08	DHB						
1						D	1-9	21/08/08	ARETINO						
						С	1,2,6	20/03/08	ARETINO						
						В	1,2,6	14/03/08	DHB						
						REVISION	SHEET	DATE	NAME						
J															
						REFERENCE	: 010798.prg - 010798.001								
NDUCT	OTHER	<sub>2M</sub>   <b>4</b>	1GL 20 T	TKS COMPASS HDGL 1		CP: 020286 Fion: DOS 1279									
				SH FREQUENCY INDUCTION HEATER											
DATE: 12/02/08 DRAFTSMAN: DHEUR B	3.			GENERAL INFORMATIONS	D	DRAWING NR: 010798 FOLIO 1/7									
0 1	2	3 4	5 6	7 8 9 10 11	12	13	14 15 16								





	0 1	2	3	4	5	6 7	8	9	10	11	12		13	14 15 16 17 18				
CARLE			CABLE	DEFINITIO	N	OT LANGUEST				ш								
CABLE NUMBER	FROM	то	CORES QU AVAILABLE	UTILIZE	CORES SECTION mm²	QUANTITY CABLE	CABLE TYP	PE	A : OTHER B : INDUCTOTHERM	DWA DWA	480v 60Hz 220v 60Hz	110v 60Hz	24v DC	OBSERVATIONS  VERY A TOUR OBSERVATIONS				
A W1	TRANSFO1	EC1	1	15	240	5x1 CABLES PER PHASE		NSGAFOU	А	500MCM				POWER BREAKER FIRST RECTIFIER A				
W2	TRANSFO2	EC1	1	15	240	5x1 CABLES PER PHASE		NSGAFOU	А	500MCM				POWER BREAKER SEC. RECTIFIER				
W3																		
B W4.1	EC1	X1	3G	2	2.5	1		NYY	В	13				INVERTER AUXILIARIES B				
W4.2	X1	X2	3G	2	2.5	1		NYY	В	13			1	INVERTER AUXILIARIES				
W4.3	X2	EC2	3G	2	2.5	1		NYY	В	13				INVERTER SLAVE AUXILIARIES				
с														c				
W5.1	EC1	X1	10	6	0.5	1	SCREENED	LIYCY	В	20				INVERTER DIGITAL CONTROL				
W5.2	X1	X2	10	6	0.5	1	SCREENED	LIYCY	В	20				INVERTER DIGITAL CONTROL				
D W5.3	X2	EC2	10	6	0.5	1	SCREENED	LIYCY	В	20				INVERTER SLAVE DIGITAL CONTROL D				
W6.1	EC1	X1	10	7	0.5	1	SCREENED	LIYCY	В	20				INVERTER DIGITAL CONTROL				
E W6.2	X1	X2	10	7	0.5	1	SCREENED	LIYCY	В	20				INVERTER DIGITAL CONTROL E				
W6.3	X2	EC2	10	7	0.5	1	SCREENED	LIYCY	В	20				INVERTER SLAVE DIGITAL CONTROL				
F W7.1	EC1	X1	3	3	0.5	1	SCREENED	LIYCY	В	20				INVERTER ANALOGICAL CONTROL F				
W7.2	X1	X2	3	3	0.5	1	SCREENED	LIYCY	В	20				INVERTER ANALOGICAL CONTROL				
W7.3	X2	EC2	3	3	0.5	1	SCREENED	LIYCY	В	20				INVERTER MASTER ANALOGICAL CONTROL				
G W7.4														G				
W8.1	EC1	X1	1	1	240	11		NSGAFOU	В	500MCM				DC POSITIVE CABLE - DC POWER RECTIFIER				
W8.2	X1	EC2	1	1	240	11	EXTRA FLEXIBLE	NSGAFOU	В	500MCM			1	DC POSITIVE CABLE - DC POWER RECTIFIER				
н W9.1	EC1	X1	1	1	240	11		NSGAFOU	В	500MCM			1	DC POSITIVE CABLE - DC POWER RECTIFIER				
W9.2	X1	EC2	1	1	240	11	EXTRA FLEXIBLE	NSGAFOU	В	500MCM			4	DC POSITIVE CABLE - DC POWER RECTIFIER				
1													_	1				
													_					
													_					
J													$\perp$	J				
													$\perp$					
W20	CUSTOMER	EC1	3	3	4	1		NYY	А	11			DES	AUXILIARY SUPPLY				
	NDHCI	OTHERN	Л	41GL20 TKS COMPASS HDGL 1									REFERENCE: 010798.prg - 010798.004 CP: 020286 Fion: DOS 1279.81					
DATE	12/02/08		· #	CABLE LIST										REVISION L				
DRAFT	SMAN: DHEUR E	3.				C	ARLF I	_15T			DRAWING NR: 010798 FOLIO 4/7							

	0 1	2	3	4	5	6	7	8 9	10		11	12		13	14 15 16 17 18
CAPAE			CABLE	DEFINITION	NC	OTTA NAME AND A STATE OF THE ST				Tr.	1				
CABLE NUMBER	FROM	ТО	CORES QUA AVAILABLE	NTITY UTILIZE	CORES SECTION MM2	QUANTITY CABLE	(	CABLE TYPE	A : OTHER B : INDUCTOTHERM	PRECABL	AWG	480v 60Hz 220v 60Hz	110v 60Hz	24v DC	OBSERVATIONS
A W21.1	EC1	X1	7	5	0.75	1	SCREENE	D LIYCY	В		18				INVERTER MANUAL CONTROL PANEL A
W21.2	X1	X2	7	5	0.75	1	SCREENE	D LIYCY	В		18				INVERTER MANUAL CONTROL PANEL
W21.3	X2	EC2	7	5	0.75	1	SCREENE	D LIYCY	В		18				INVERTER MANUAL CONTROL PANEL
B W22.1	EC1	X1	10	8	0.5	1	SCREENE	D LIYCY	В		20				INVERTER MANUAL CONTROL PANEL B
W22.2	X1	X2	10	8	0.5	1	SCREENE	D LIYCY	В		20				INVERTER MANUAL CONTROL PANEL
W22.3	X2	EC2	10	8	0.5	1	SCREENE	D LIYCY	В		20				INVERTER MANUAL CONTROL PANEL
C W23															c
W24															
W25.1	EC1	X1	3G	2	1.5	1		LIYY	В		15				EMERGENCY STOP
D W25.2	X1	X2	3G	2	1.5	1		LIYY	В		15				EMERGENCY STOP D
W26.1	EC1	X1	3G	2	1.5	1		LiYY	В		15				INFO EMERGENCY STOP CUSTOMER
W26.2	X1	X2	3G	2	1.5	1		LiYY	В		15				INFO EMERGENCY STOP CUSTOMER
E W28.1	EC1	X1	3G	2	1.5	1		NYY	В		15				120V 60 Hz FOR CUSTOMER E
W28.2	X1	X2	3G	2	1.5	1		NYY	В		15				120V 60 Hz FOR CUSTOMER
W28.3	X2	EC2	3G	2	1.5	1		NYY	В		15				120V 60 Hz FOR CUSTOMER
F															F
W36.1	EC1	X1	1	1	95	1		VOBST95YG	В		000				RECTIFIER CUBICLE TO TROLLEY GROUND
W36.2	X1	BUSBAR	1	1	95	1		VOBST95YG	EXTRA FLEXIBLE B		000				INVERTER SLAVE CUBICLE GROUND
G W36.3	BUSBAR	X2	1	1	6	1		VOBST6YG	В		9				TERMINAL BOX X2 GROUND G
W36.4	BUSBAR	EC2	1	1	95	1		VOBST95YG	В		000				INVERTER SLAVE CUBICLE GROUND
W36.5															
н W37	EC1	GND	1	1	95	1		VOBST95YG	В		000				RECTIFIER CUBICLE GROUND H
W38															
I W39															1
W40															
W41															
J W42															J
W43															
W44															
	NDUCTOTHERM 41GL20 TKS COMPASS HDGL 1								_ 1	REFERENCE: 010798.prg - 010798.005  CP: 020286 Fion: DOS 1279.81					
DATE:	DATE: 12/02/08 DRAFTSMAN: DHEUR B.  CABLE LIST										DF	RAY	WI	NG NR: 010798 REVISION 0 FOLIO 5/7	
DRAFTSN	MAN: DHEUR E	3.													

	0 1	2	3	4	5	6	7	8	9	10	1	11	12		13	14 15 16 17 18		
CARLE			CABLE	DEFINITION	NC	OLIA NITITSV					ш		2 2	z		ri e		
CABLE NUMBER	FROM	TO	CORES QUA		CORES SECTION	QUANTITY CABLE	CAE	BLE TYPE			CABL	AWG	480v 60Hz	110v 60Hz	24v DC	OBSERVATIONS		
			AVAILABLE	UTILIZE	MM2	1				A : CUSTOMER B : INDUCTOTHERM	PRE		88 2	Ĭ	2	*		
A W45	TOWER +CIO 04	EC1	2	2	0.64	1	LIAISON PROF	FIBUS 6XV1830-	0EH10	А						INVERTER INSTALLATION INFORMATION A		
W49	CUSTOMER	EC1	3G	2	1.5	1			LIYY	А		15				CUSTOMER EMERGENCY STOP		
B W50.1	EC1	X1	7	5	0.75	1	SCREENED		LIYCY	А		18				CLAMP OPEN-CLOSE MOVEMENT CONTROL B		
W50.2	X1	X2	7	5	0.75	1	SCREENED		LIYCY	А		18				CLAMP OPEN-CLOSE MOVEMENT CONTROL		
W50.3	X2	Х3	7	5	0.75	1	SCREENED		LIYCY	В		18				CLAMP OPEN-CLOSE MOVEMENT CONTROL		
c W51.1	EC1	X1	10	6	0.5	1	SCREENED		LIYCY	А		20				CLAMP OPEN-CLOSE MOVEMENT LIMIT SWITCH + MANUAL CONTROL C		
W51.2	X1	X2	10	6	0.5	1	SCREENED		LIYCY	А		20				CLAMP OPEN-CLOSE MOVEMENT LIMIT SWITCH + MANUAL CONTROL		
W51.3	X2	Х3	10	6	0.5	1	SCREENED		LIYCY	В		20				CLAMP OPEN-CLOSE MOVEMENT LIMIT SWITCH + MANUAL CONTROL		
D W52.1	EC1	X1	4	4	1.5	1			LiYY	В		15				AUTO-MANU/OPEN/CLOSE D		
W52.2	X1	X2	4	4	1.5	1			LiYY	В		15				AUTO-MANU/OPEN/CLOSE		
W52.3	X2	Х3	4	4	1.5	1			LiYY	В		15				AUTO-MANU/OPEN/CLOSE		
E																E		
W54.1																		
W54.2																		
F W55.1																F		
W55.1																		
W77	X4	ACM 1	3+1	3+1	16	1			NYY	А		5				POWER SUPPLY PUMP 1		
G W78	X4	ACM 2	3+1	3+1	16	1			NYY	А		5				POWER SUPPLY PUMP 2		
W79	X4	TIS1	2+1	2+1	1.5	1	SCREENED		LIYCY	А		15				WATER TEMPERATURE		
W80	X4	PS1	2+1	2+1	1.5	1	SCREENED		LIYCY	А		15				WATER PRESSURE		
н W81	X4	FIS1	2+1	2+1	1.5	1	SCREENED		LIYCY	А		15				WATER FLOW RECTIFIER		
W82	X4	FIS2	2+1	2+1	1.5	1	SCREENED		LIYCY	А		15				WATER FLOW INVERTER		
W83	X4	FIS3	2+1	2+1	1.5	1	SCREENED		LIYCY	А		15				WATER FLOW INDUCTOR		
W84	CUSTOMER	X4	3+1	3+1	16	1			NYY	А		5				WATER UNIT POWER SUPPLY		
W85	EC1	X4	2	2	0.64	1	LIAISON PROF	FIBUS 6XV1830-0	0EH10	А						WATER FLOW INFORMATION		
W86	TANK	X4	4	4	1.5	1	SCREENED		LIYCY	А		15				WATER TANK LEVEL		
J W87																J		
W88	EC1	X4	2	2	1.5	1	SCREENED		LIYCY	А		15				WATER FLOW FAULT		
W89	X4	GND	1	1	35	1		VOBS	ST35YG	В		1				WATER COOLING SYSTEM GROUND		
			-	11	CLO	n TV	S C C		166	, HDV	· · ·	1		REFE				
	MDUCT	TOTHERM	41GL20 TKS COMPASS HDGL 1										CP: 020286 Fion: DOS 1279.81					
DATE:	12/02/08 MAN: DHEUR E	3		CABLE LIST										DRAWING NR: 010798 FOLIO 6/7				
DIAI 19.	DITEON	<i>-</i> .		l									1					